

BPS 204-Client

The screenshot shows the BPS204 Client software interface. On the left, there are callout boxes for various controls: Pulse Level, Frequency, Pulse Polarity, Pulse Mode, Trigger Mode, Probe Trigger, Main Delay, Delta Delay, and Control. The software window displays the following settings:

- Pulse Level:** 0200 V (slider from 50 to 1k)
- Frequency:** 00100.0Hz (slider from 0.1 to 10k)
- Pulse Polarity:** Positive (selected), Negative
- Pulse Mode:** Single Pulse, Double Pulse (selected)
- Trigger Mode:** Free Running (selected), Sync Single Trigger, Sync Double Trigger
- Probe:** Single Cable, Dual Cable
- Pulse Delays:** Main Delay: 000 steps, Delta Delay: 040 steps

At the bottom, there is a "Start Pulsing" button and status information: Source: BPS204, Probe: ICI-DP HH500-15.