

### Short description

The dongle is included in the software delivery and needs a free USB port. With an inserted dongle only the software can record measurement data from external devices.