

Contents E1 set:

Burst generator: Magnetic field probe: Optical Sensor: E-field sources: Accessories E1 set User manual System case with quick guide

SGZ 21 MS 02



S21 with optical fibre Magnetic field sources: BS 02; BS 04DB; BS 04DU; BS 05D ES 00; ES 01; ES 02; ES 05D; ES 08D

Usage:

The E1 immunity development system simulates interference processes within the device. Disturbance currents, electric and magnetic fields are injected directly into the electronic modules in different ways to determine the susceptible structures on the circuit board, understand the coupling mechanism and enable the implementation of the optimum modifications

Immunity development system E1 set

